

Subject	Page No.	Subject	Page No.
<b>A</b>			
Access Hole Covers - Tail Gate Inner Panel . . . . .	9-2	Arm Rest and Curtain - Standard Full Width Seat Back - Standard Front Seat . . . . .	15-21
Actuator - 68069 & 68169 Styles - Rear Door Lock Vacuum . . . . .	6-96	Arm Rest (Center) and Curtain, Rear Seat Back . . . . .	15-39
Actuator, Horizontal - Power Operated Four-Way Adjuster - Strato Front Seat . . . . .	15-36	Arm Rest and Support - Standard Full Width Seat Back - Standard Front Seat . . . . .	15-21
Actuator, Horizontal - Standard Front Seats - "A" Body - Four-Way . . . . .	15-9	Arm Rest Assembly - Notch Down and Strato Seat Back - Standard Front Seat . . . . .	15-22
Actuator, Horizontal - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-13	Arm Rest, Center - Standard Front Seat . . . . .	15-21
Actuator, Horizontal - Standard Front Seat - "B, C & E" Body - Six-Way . . . . .	15-14	Arm Rest Hanger Plate (Center) and Linkage, Rear Seat Back . . . . .	15-39
Actuator, Lock Vacuum - Front Doors . . . . .	6-39	Arm Rest Support - Notch Down and Strato Seat Back - Standard Front Seat . . . . .	15-22
Actuator, Vacuum Door Lock - Front Doors . . . . .	6-79	Auxiliary Sealing Strip - Front and Rear Door Bottom . . . . .	6-3
Adhesive Caulking . . . . .	4-1	<b>B</b>	
Adjuster Assembly - Manually Operated - Standard Front Seats . . . . .	15-3	Back Assembly, Folding Rear Seat . . . . .	15-38
Adjuster Assembly - Power Operated - Standard Front Seats . . . . .	15-3	Back Assembly, Seat - "A-39" Styles with Arm Rest - Standard Front Seat . . . . .	15-18
Adjuster Jackscrew - Power Operated Four-Way - Front Strato Seat . . . . .	15-36	Back Assembly, Seat - Four Door with Standard Front Seat . . . . .	15-17
Adjuster, Manually Operated Bucket Seat - Front Strato . . . . .	15-31	Back Assembly, Seat (Left or Right) - Two Door with Standard Front Seat . . . . .	15-18
Adjuster Mechanism Lubrication - Front Seat . . . . .	2-6	Back Assembly - Standard Front Bucket . . . . .	15-25
Anchorage (Closed Styles), Roof - Shoulder Straps . . . . .	15-59	Back Assembly, Strato - Full Width (16639 Styles) - Front Seat . . . . .	15-27
Anchorage, Floor - Shoulder Straps . . . . .	15-60	Back Assembly, Strato - Full Width (Except 16639) - Front Seat . . . . .	15-26
Anchorage, Quarter (Convertibles) - Shoulder Straps . . . . .	15-60	Back Curtain Assembly - Complete . . . . .	13-20
Arm Rest - Rear Quarter . . . . .	14-10	Back Headrest - Full Width - Standard Front Seat . . . . .	15-21
Arm Rests - Door . . . . .	14-2	Back Headrest, Strato - Front Seat . . . . .	15-28
Arm Rest and Curtain - Notch Down and Strato Seat Back - Standard Front Seat . . . . .	15-21		

Subject	Page No.	Subject	Page No.
Back Headrest Supports, Strato - Front Seat . . . . .	15-29	Back Panel, Strato - Four Door Styles - Front Seat . . . . .	15-27
Back Headrest Support Guide Tube, Strato - Front Seat . . . . .	15-28	Back Window, Adhesive Caulking . . . . .	4-15
Back Lock - Standard Front Bucket . . . . .	15-26	Bail Type Retractor, Seat Belt . . . . .	15-55
Back Lock and Striker - Reclining Front Strato Seat . . . . .	15-32	Belts, Seat - Front and Rear . . . . .	15-54
Back Lock Control Assembly - Reclining Front Strato Seat . . . . .	15-33	Bolt Lubrication - Rotary and Fork - Door Lock . . . . .	2-1
Back Lock Control Support - Reclining Front Strato Seat . . . . .	15-33	Body Ventilation Description - All Except 26657 and "E" Body . . . . .	5-1
Back Lock, Seat - "C & E" - Standard Front Seat . . . . .	15-19	Body Ventilation Description - 26657 and "E" Body Styles . . . . .	5-5
Back Lock, Seat - "A, B & Z" - Standard Front Seat . . . . .	15-19	Bucket Assembly, Manually Operated - Front Seat . . . . .	15-24
Back Lock, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Style . . . . .	15-52	Bucket Seat Adjuster, Manually Operated - Front Strato . . . . .	15-33
Back Trim and Spring, Rear Seat - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47	Bucket Seat Back Stop Cable or Spring, Passenger Front . . . . .	15-25
Back Trim and Spring, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-50	Buckle Retainer - Shoulder Straps . . . . .	15-60
Back Trim, Folding Third Seat - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42	<b>C</b>	
Back Trim or Seat Back Panel, Third Seat - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-54	Cams and Guides Lubrication - Rear Quarter Window Regulator . . . . .	2-4
Back Panel and Filler, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52	Cams and Guides Lubrication - Window Regulator - Styles with Upper Frames . . . . .	2-2
Back Panel or Back Trim, Third Seat - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-54	Cam and Regulator Lubrication - Tail Gate Window (Station Wagon) . . . . .	2-5
Back Panel, Folding Third Seat - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42	Cam, Inner Panel - All Except "X" Styles - Rear Door . . . . .	6-96
Back Panel, Strato - Two Door Styles . . . . .	15-28	Cam, Inner Panel - Front Doors . . . . .	6-36
		Casting, Ventilator - "X-37" Styles - Front Doors . . . . .	6-44
		Catch Clips - Folding Top - Manually Operated Tops . . . . .	13-36

Subject	Page No.	Subject	Page No.
Center and Side Trim Panels - Compartment Shelf - Cadillac "E" Styles . . . . .	14-27	Compartment Shelf Center Finishing Panel - Oldsmobile and Buick "E" Styles . . . . .	14-26
Center Arm Rest - Standard Front Seat . . . . .	15-21	Compartment Shelf Side and Center Trim Panels - Cadillac "E" Styles . . . . .	14-27
Center Arm Rest and Curtain, Rear Seat Back . . . . .	15-39	Compartment Shelf Side Finishing Panels - Oldsmobile and Buick "E" Styles . . . . .	14-26
Center Arm Rest Hanger Plate and Linkage, Rear Seat Back . . . . .	15-39	Compartment Shelf Trim Assembly - All Except "E" Styles . . . . .	14-25
Center Finishing Panel - Compartment Shelf - Oldsmobile and Buick "E" Styles . . . . .	14-26	Control Assembly - Reclining Front Strato - Seat Back Lock . . . . .	15-33
Center Pillar Weatherstrips - "C-69" Styles - Front and Rear Doors . . . . .	6-14	Control, Lock Remote - Front Doors . . . . .	6-36
Channel Cam, Lower Sash - All Except "X" Styles - Rear Door Window . . . . .	6-96	Control Support - Reclining Front Strato Seat Back Lock . . . . .	15-33
Clips, Spring - Front and Rear Doors . . . . .	6-6	Convertible Top Linkage Lubrication . . . . .	2-6
Cloth and Vinyl Coated Headlining - All Styles . . . . .	11-1	Cover - Instrument Panel - Chevrolet . . . . .	5-7
Compartment Door - Instrument Panel - All Except "E" and Cadillac "C" . . . . .	5-5	Cover Panel - Spare Tire - "B" Station Wagon Styles . . . . .	14-18
Compartment Door Lubrication - Instrument Panel . . . . .	2-1	Cover Panel and Filler Panel, Luggage Compartment - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-54
Compartment Floor Panel (At Kick-Up) - Station Wagon Rear Seats - "B" Body . . . . .	15-43	Cover - Tail Gate Inner Panel . . . . .	9-1
Compartment Front and Rear Panel Hinge, Luggage - Station Wagon Rear Seat - "B" Body . . . . .	15-41	Curtain and Arm Rest - Notch Down and Strato Seat Back - Standard Front Seat . . . . .	15-21
Compartment Hinge and Torque Rod Lubrication - Rear . . . . .	2-5	Curtain and Arm Rest - Standard Full Width Seat Back - Standard Front Seat . . . . .	15-21
Compartment Lid - Front - Corvair . . . . .	5-8	Curtain and Center Arm Rest, Rear Seat Back . . . . .	15-39
Compartment Lid Lock Lubrication - Rear . . . . .	2-5	Cushion - Rear Seat . . . . .	15-37
Compartment Lubrication - Front Lid Lock . . . . .	2-2	Cushion, Folding Third Seat - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42
Compartment Pan Side Filler Panel - Station Wagon Rear Seat - "B" Body . . . . .	15-40	Cushion, Rear Seat - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-46
Compartment Rear Panel, Luggage - Two Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-41	Cushion, Second Seat (Full Width or Split Seat ) - Station Wagon Rear Seats - "B" . . . . .	15-43

Subject	Page No.	Subject	Page No.
Cushion, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-50	Door Pull Handles . . . . .	14-1
Cushion Trim, Third Seat - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-53	Door Trim Assemblies - "A-F" Styles . . . . .	14-6
Cylinder Assembly, Lock - Front Doors . . . . .	6-39	Door Trim Assemblies - "B-C-E" Styles . . . . .	14-4
Cylinder - Front Compartment Lid Lock - Corvair . . . . .	5-9	Door Trim Assemblies - "X" Styles . . . . .	14-8
Cylinder, Luggage Compartment Lock - 15-16000 Styles - Station Wagon Rear Seats "B" Body . . . . .	15-45	Door Trim Assemblies - "Z" Styles . . . . .	14-9
<b>D</b>		Door Wedge Plates - "67" Styles - Front Doors . . . . .	6-78
Division Channel, Stationary Ventilator - "X-35 & 69" Styles - Rear Door Window . . . . .	6-97	Door Window Regulator Cams and Guides Lubrication - Styles with Upper Frames . . . . .	2-2
Door Arm Rests . . . . .	14-2	Door Window Regulator and Cams Lubrication - Styles with Upper Frames . . . . .	2-2
Door Bottom Auxiliary Sealing Strip - Front and Rear Doors . . . . .	6-3	Drain Hole Sealing Strips - Bottom - Tail Gate . . . . .	9-12
Door Bottom Drain Hole Sealing Strips - Front and Rear Doors . . . . .	6-3	Drain Hole Sealing Strips - Front and Rear Door Bottom . . . . .	6-3
Door Hinge Hold-Open Assembly Lubrication - Front Door . . . . .	2-1	Drive Cables and Transmission Assembly - Power Operated Four-Way Adjuster - Front Strato Seat . . . . .	15-36
Door Hinge Hold-Open Assembly Lubrication - Rear Door . . . . .	2-1	Drive Cables, Horizontal and Vertical - Standard Front Seats - "A" Body - Four-Way . . . . .	15-11
Door Hinge Lubrication - Gas Tank Filler . . . . .	2-5	Drive Cables, Horizontal and Vertical - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-13
Door Jamb Switch Lubrication . . . . .	2-2	Drive Cables, Vertical and Horizontal - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-16
Door Lock Actuator, Vacuum - Front Doors . . . . .	6-79	<b>E</b>	
Door Lock Fork Bolt and Rotary Bolt Lubrication . . . . .	2-1	Electric Motor - "C" Body - Standard Front Seats - Two-Way . . . . .	15-6
Door Lock Mechanism and Lock Parts Lubrication . . . . .	2-2	Electric Motor - Front Door Window Regulator . . . . .	6-72
Door Lock Striker Lubrication . . . . .	2-1	Electric Motor - Standard Front Seats - "A" Body - Four-Way . . . . .	15-7
Door Lock System, Vacuum - Front Door . . . . .	6-78	Electric Motor - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-12
Door Locks - Instrument Panel - All Except "E" and Cadillac "C" . . . . .	5-7	Electric motor - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-14
Door Lubrication - Instrument Panel Compartment . . . . .	2-1		

Subject	Page No.	Subject	Page No.
Electric Motor Removal - Rear Door Window Regulator . . . . .	6-116	Filler Door Hinge Lubrication - Gas Tank . . . . .	2-5
Electric Regulator Motor Assembly - Tail Gate Window . . . . .	9-5	Filler Panel and Cover Panel, Luggage Compartment - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-54
Electric Release Lock - Rear Compartment Lid . . . . .	8-11	Filler Panel, Compartment Pan Side - Station Wagon Rear Seat - "B" Body . . . . .	15-40
Electrical Checking Procedure - Hydro-Electric System . . . . .	13-30	Filler Panel, Folding Rear Seat Back . . . . .	15-38
Engine Lid - Rear Compartment - Corvair . . . . .	8-2	Filler Panel, Rear Floor - Station Wagon Folding Two Seat Styles - "A" Except "65" . . . . .	15-47
Engine Lid Latch - Rear Compartment - Corvair . . . . .	8-7	Filler Panel, Rear Floor - Station Wagon Rear Seats - "B" Body . . . . .	15-43
Engine Lid Latch Striker - Rear Compartment - Corvair . . . . .	8-7	Flocked Type Headlining . . . . .	11-4
Engine Lid Support - Rear Compartment Lid - Corvair . . . . .	8-4	Floor Anchorage - Shoulder Straps . . . . .	15-60
Exterior Moldings . . . . .	17-1	Floor Covering, Rear Compartment - Station Wagon Styles with Rubber Mat - "A" Body Except "65" . . . . .	15-46
Chevrolet Styles - "A" Body . . . . .	17-5	Floor Mount, Retractor Type - Seat Belts . . . . .	15-55
"B" Body . . . . .	17-16	Floor Mounts with Plastic Cover, Standard - Seat Belts . . . . .	15-55
"F" Body . . . . .	17-27	Floor Pan Linkage, Second Seat Front - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
"X" Body . . . . .	17-29	Floor Pan Linkage, Second Seat Rear - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
"Z" Body . . . . .	17-35	Floor Panel (At Kick-Up), Compartment - Station Wagon Rear Seats - "B" Body . . . . .	15-43
Pontiac Styles - "A" Body . . . . .	17-39	Floor Panel (At Kick-Up), Rear Compartment, Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47
"B" Body . . . . .	17-49	Floor Panel and Third Seat - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-53
Oldsmobile Styles - "A" Body . . . . .	17-63	Floor Panel Covering, Rear Compartment - Station Wagon Styles with Floor Carpet - "A" Body Except "65" Styles . . . . .	15-46
"B-C" Body . . . . .	17-74		
"E" Body . . . . .	17-85		
Buick Styles - "A" Body . . . . .	17-87		
"B-C" Body . . . . .	17-98		
"E" Body . . . . .	17-106		
Cadillac Styles - "C" Body . . . . .	17-109		
"D" Body . . . . .	17-116		
"E" Body . . . . .	17-119		
<b>F</b>			
Fabric Cover - Tail Gate . . . . .	12-10		
Fabric Roof Covers (All Styles Except Station Wagons) . . . . .	12-1		
Fabric Roof Covers (Station Wagon Styles) . . . . .	12-6		
Filler and Back Panel, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52		

Subject	Page No.	Subject	Page No.
Floor Panel Covering, Rear Compartment - Station Wagon Styles with Vinyl Mat - "A" Body Except "65" Styles . . . . .	15-46	Front and Rear Panel Assembly, Luggage Compartment - Two Seat Styles Station Wagon Rear Seat - "B" Body . . . . .	15-41
Fluid Control Valve - Hydro-lectric System . . . . .	13-29	Front and Rear Panel Hinge, Luggage Compartment - Station Wagon Rear Seat - "B" Body . . . . .	15-41
Folding Rear Seat Back - Corvair . . . . .	15-38	Front Back Assembly - Standard Bucket . . . . .	15-25
Folding Rear Seat Back Assembly . . . . .	15-38	Front Back Lock - Standard Bucket . . . . .	15-26
Folding Rear Seat Back Filler Panel . . . . .	15-38	Front Bucket Seat Back Stop Cable or Spring, Passenger . . . . .	15-25
Folding Rear Seat Back Linkage . . . . .	15-38	Front Compartment Description - Corvair . . . . .	5-8
Folding Seat Back - "F" Body - Rear Seat . . . . .	15-38	Front Compartment Lid - Corvair . . . . .	5-8
Folding Seat Linkage Lubrication . . . . .	2-5	Front Compartment Lid Gutter Weatherstrip - Corvair . . . . .	5-11
Folding Second Seat Back Lock - Station Wagon Folding Two Seat Styles - "A, B & X" (Except "55" & "65") . . . . .	15-48	Front Compartment Lid Lock Assembly - Corvair . . . . .	5-10
Folding Third Seat Back Panel - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42	Front Compartment Lid Lock Cylinder - Corvair . . . . .	5-9
Folding Third Seat Back Trim - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42	Front Compartment Lid Lock Lubrication . . . . .	2-2
Folding Third Seat Cushion - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42	Front Compartment Lid Lock Striker - Corvair . . . . .	5-10
Folding Third Seat Cushion, Panel and Support - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42	Front Compartment Lid Torque Rods - Corvair . . . . .	5-8
Folding Top Catch Clips - Manually Operated Tops . . . . .	13-36	Front Door Hinge Hold-Open Assembly Lubrication . . . . .	2-1
Folding Top Silencer . . . . .	13-24	Front Floor Pan Linkage, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
Folding Top Trim Assembly - Complete . . . . .	13-1	Front Guide - 26657 Style - Front Door Window . . . . .	6-76
Folding Top Trim Assembly - Less Back Curtain . . . . .	13-14	Front Guide - "B-C 47-57-67-87" Styles - Rear Quarter Window . . . . .	7-25
Foot Rest Assembly - Cadillac 68169 Styles - Standard Front Seat Back . . . . .	15-22	Front Guide and Guide Plate - 68069 & 68169 Styles - Rear Doors . . . . .	6-112
Fork Bolt and Rotary Bolt Lubrication - Door Lock . . . . .	2-1	Front Guide Assembly - Rear Quarter Window - "A-X-Z" Hardtop and Convertible Styles and "E-87" Styles . . . . .	7-25
Four-Way Adjuster, Power Operated - Front Strato Seat . . . . .	15-34		

Subject	Page No.	Subject	Page No.
Front Guide Channel - "E" Styles - Front Door Window . . . . .	6-74	Gearnut, Vertical - Standard Front Seat - "B, C & E" Body - Four-Way . . . . .	15-12
Front Panel - Oldsmobile and Buick "E" Body - Rear Compartment Lid . . .	8-3	Glass Run Channel - "B-11-35-45-69" Styles - Front Door . . . . .	6-76
Front Seats, Standard - Full Width . . . . .	15-3	Glass Run Channels - "X-11-35-69" Styles - Front Door Window . . . . .	6-75
Front Seat Assembly, Standard - Manually Operated . . . . .	15-3	Glass Run Channels - "X-37" Styles - Front Door Window . . . . .	6-75
Front Seat Adjuster Mechanism Lubrication . . . . .	2-6	Glass Run Channel - "Z" Styles - Front Door Window Rear . . . . .	6-75
Front Seat Back, Reclining . . . . .	15-30	Glass Run Channel - "A-17-39-67" Styles - Front Door Rear Window . . . . .	6-73
Front Seat Center Arm Rest - Standard Front Seat . . . . .	15-21	Glass Run Channel - Inner and Outer Strip Assemblies - Front and Rear Doors . . . . .	6-9
Front Seat Shoulder Straps . . . . .	15-55	Glass Run Channel - "A-35-55-65 & 69" Styles - Rear Door Window . . . . .	6-11
Front Trim Panel - Rear Quarter - "A" Station Wagon Styles . . . . .	14-20	Glass Run Channel - "B-35-45 & 69" Styles - Rear Door Window . . . . .	6-11
Front Trim Panel - Rear Quarter - Chevy II Station Wagon Styles . . . . .	14-24	Glass Run Channel - "X-35 & 69" Styles - Rear Door Window . . . . .	6-11
Front Vertical Gearnut - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-15	Glass Run Channel - Rear Quarter Window - "E-47" Styles . . . . .	7-26
Full Width Seat Assembly, Strato - Front . . . . .	15-23	Glass Run Channel - Tail Gate Upper - "A & B" Body . . . . .	9-13
Full Width Standard Front Seats . . . . .	15-3	Glass Run Channel - Tail Gate Upper - "X" Body . . . . .	9-14
<b>G</b>		Glass Run Channels - Tail Gate Window - Lower . . . . .	9-7
Gas Tank Filler Door Hinge Lubrication . . . . .	2-5	Guides and Cams Lubrication - Rear Quarter Window Regulator . . . . .	2-4
Gearnut Adjuster, Vertical - Power Operated Four-Way - Front Strato Seat . . . . .	15-36	Guides and Cams Lubrication - Window Regulator - Styles with Upper Frames . . . . .	2-2
Gearnut, Front Vertical - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-15	Guide and Guide Plate Assembly - All "B-C" Except "B-11-35-45-57-69" Styles - Front Door Window . . . . .	6-76
Gearnut, Horizontal - Standard Front Seats - "C" Body - Two-Way . . . . .	15-7		
Gearnut, Rear Vertical - Standard Front Seat - "B, C & E" Body - Six-Way . . . . .	15-15		
Gearnut, Vertical - Standard Front Seat - "A" Body - Four-Way . . . . .	15-8		

Subject	Page No.	Subject	Page No.
Guide Assembly - "F" Styles - Front Door Window Rear . . . . .	6-74	Hinge Adjustment - Front Doors . . . . .	6-35
Guide Assembly - Rear Quarter Window - All "F" Styles . . . . .	7-26	Hinge and Torque Rod Lubrication - Rear Compartment . . . . .	2-5
Guide Channel - "E" Styles - Front Door Window Rear . . . . .	6-74	Hinge Assembly - Tail Gate . . . . .	9-2
Guide Channel - "E" Styles - Front Door Window Front . . . . .	6-74	Hinge Hold-Open Assembly Lubrication - Front Door . . . . .	2-1
Guide Channels - "A-39" Styles Rear Door Window . . . . .	6-111	Hinge Hold-Open Assembly Lubrication - Rear Door . . . . .	2-1
Guide Plate and Front Guide - 68069 and 68169 Styles - Rear Doors . . . . .	6-112	Hinge, Luggage Compartment Front and Rear Panel - Station Wagon Rear Seat - "B" Body . . . . .	15-41
Guide Plate - "A-17-39-67" Styles - Front Door Window Sash Channel . . . . .	6-54	Hinge Lubrication - Gas Tank Filler Door . . . . .	2-5
Guide Tube, Strato Back Headrest Support - Front Seat . . . . .	15-28	Hinge Lubrication (Station Wagon) - Tail Gate . . . . .	2-5
Gutter Weatherstrip - Front Compartment Lid - Corvair . . . . .	5-11	Hinge Removal - Front Doors . . . . .	6-22
<b>H</b>		Hold-Open Assembly Lubrication - Front Door Hinge . . . . .	2-1
Handles - Inside . . . . .	14-2	Hold-Open Assembly Lubrication - Rear Door Hinge . . . . .	2-1
Handles - Outside - Front and Rear Doors . . . . .	6-6	Horizontal Actuator - Power Operated Four-Way Adjuster - Strato Front Seat . . . . .	15-36
Handle - Rear Quarter Window Regulator . . . . .	14-9	Horizontal Actuator - Standard Front Seats - "A" Body - Four-Way . . . . .	15-9
Headlining - Cloth and Vinyl Coated - All Styles . . . . .	11-1	Horizontal Actuator - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-13
Headlining - Flocked Type . . . . .	11-4	Horizontal Actuator - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-14
Headlining - "55 and 65" Station Wagon Styles . . . . .	11-6	Horizontal Adjuster, Power Operated - Front Strato Seat . . . . .	15-34
Headrest, Seat Back - Full Width Seat - Standard Front Seat . . . . .	15-21	Horizontal and Vertical Drive Cables - Standard Front Seats - "A" Body - Four-Way . . . . .	15-11
Headrest, Strato Back - Front Seat . . . . .	15-28	Horizontal and Vertical Drive Cables - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-13
Headrest Support Guide Tube, Strato Back - Front Seat . . . . .	15-28	Horizontal and Vertical Drive Cables - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-16
Headrest Supports, Strato Back - Front Seat . . . . .	15-29		
Hinges - Rear Doors . . . . .	6-87		

Subject	Page No.	Subject	Page No.
Horizontal Gearnut - Standard Front Seats - "C" Body - Two-way . . . . .	15-7	Instrument Panel Compartment Door - All Except "E" and Cadillac "C" . . . . .	5-5
Horizontal Jackscrew - Standard Front Seats - "C" Body - Two-Way . . . . .	15-7	Instrument Panel Compartment Door Lubrication . . . . .	2-1
Hydraulic Checking Procedure - Hydro-Electric System . . . . .	13-31	Instrument Panel Cover - Chevrolet . . . . .	5-7
Hydraulic Cylinder - Rear Compartment Lid Mechanical Pull-Down Unit - Cadillac . . . . .	8-9	Instrument Panel Door Locks - All Except "E" and Cadillac "C" . . . . .	5-7
Hydro-lectric System - Folding Top . . . . .	13-26		
		<b>J</b>	
		Jackscrew, Adjuster - Power Operated Four-Way - Front Strato Seat . . . . .	15-36
<b>I</b>		Jackscrew, Horizontal - Standard Front Seats - "C" Body - Two-Way . . . . .	15-7
Inner and Outer Strip Assemblies - Tail Gate Window . . . . .	9-12	Jackscrew, Standard Front Seat - "A" Body - Four-Way . . . . .	15-10
Inner Linkage, Second Seat Split Back - Station Wagon Rear Seats - "B" Body . . . . .	15-45	Jamb Switch - Electric Styles - Tail Gate . . . . .	9-8
Inner Linkage, Second Seat Side - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51	Jamb Switch Lubrication - Door . . . . .	2-2
Inner Panel Access Hole Covers - Tail Gate . . . . .	9-2		
Inner Panel Cam - All Except "X" Styles - Rear Door . . . . .	6-96	<b>L</b>	
Inner Panel Cam - Front Doors . . . . .	6-36	Latch - Rear Compartment Engine Lid - Corvair . . . . .	8-7
Inner Panel Cover - Tail Gate . . . . .	9-1	Lid - Front Compartment - Corvair . . . . .	5-8
Inner Panel Sealing - Rear Quarter . . . . .	7-2	Lid - Rear Compartment - All Except Corvair . . . . .	8-1
Inner Panel Water Deflector - Front and Rear Doors . . . . .	6-4	Lid Emblem and Lock Cylinder Assembly - Rear Compartment - Cadillac . . . . .	8-4
Inner Panel Water Deflector - Tail Gate . . . . .	9-1	Lid Hinge Strap - Rear Compartment Lid . . . . .	8-3
Inner Sealing Strip - Rear Quarter Window Rear Vertical - "C-47" Styles . . . . .	7-9	Lid Latch - Rear Compartment Engine - Corvair . . . . .	8-7
Inside Handles . . . . .	14-2	Lid Latch Striker - Rear Compartment Engine - Corvair . . . . .	8-7
Inside Handle - "B" Styles - Tail Gate Remote Control . . . . .	9-9		

Subject	Page No.	Subject	Page No.
Lid Lock -		Lid Torque Rods -	
Rear Compartment . . . . .	8-6	Front Compartment -	
Lid Lock Assembly -		Corvair . . . . .	5-8
Front Compartment -		Lid Vacuum Release Unit -	
Corvair . . . . .	5-10	Rear Compartment . . . . .	8-7
Lid Lock Cylinder -		Lid Vacuum Unlocking System -	
Front Compartment -		Rear Compartment . . . . .	8-7
Corvair . . . . .	5-9	Linkage and Center Arm Rest Hanger	
Lid Lock Cylinder -		Plate, Rear Seat Back . . . . .	15-39
Rear Compartment -		Linkage, Folding Rear Seat Back . . . . .	15-38
Oldsmobile "E" . . . . .	8-5	Linkage Lubrication -	
Lid Lock Cylinder -		Convertible Top . . . . .	2-6
Rear Compartment -		Linkage Lubrication -	
Pontiac 26657 . . . . .	8-5	Folding Seat . . . . .	2-5
Lid Lock Cylinder -		Linkage, Second Seat Back	
Rear Compartment -		(Full Width Both Sides, Split Seat -	
Chevrolet "A & F", Pontiac "A & B"		Outer Only) . . . . .	15-44
(Except 26657), Oldsmobile "B" . . . . .	8-4	Linkage, Second Seat Front Floor Pan -	
Lid Lock Cylinder -		Right or Left - Station Wagon Folding	
Rear Compartment -		Rear Seat - "A-65" Styles . . . . .	15-51
Chevrolet "B & X",		Linkage, Second Seat Rear Floor Pan -	
Buick "A, B, C & E"		Right or Left - Station Wagon Folding	
and Oldsmobile "A & C" Styles . . . . .	8-4	Rear Seat - "A-65" Styles . . . . .	15-51
Lid Lock Electric Release Unit -		Linkage, Second Seat Side Inner -	
Rear Compartment -		Right or Left - Station Wagon Folding	
Pontiac "A & B" . . . . .	8-11	Rear Seat - "A-65" Styles . . . . .	15-51
Lid Lock Lubrication -		Linkage, Second Seat Side Outer -	
Front Compartment . . . . .	2-2	Right or Left - Station Wagon Folding	
Lid Lock Lubrication -		Rear Seat - "A-65" Styles . . . . .	15-52
Rear Compartment . . . . .	2-5	Lock - Rear Compartment Lid . . . . .	8-6
Lid Lock Striker -		Lock Actuator, Vacuum Door -	
Front Compartment -		Front Doors . . . . .	6-79
Corvair . . . . .	5-10	Lock Assembly -	
Lid Lock Striker -		"B-35-45-69" Styles -	
Rear Compartment . . . . .	8-6	Rear Door . . . . .	6-87
Lid Lock Striker Engagement -		Lock Assembly -	
Rear Compartment - All Except		Front Compartment Lid -	
Corvair and Cadillac with		Corvair . . . . .	5-10
Mechanical Closing Unit . . . . .	8-6	Lock Assembly -	
Lid Mechanical Pull-Down Unit -		Tail Gate . . . . .	9-9
Rear Compartment -		Lock Assembly and Vacuum Actuator -	
Cadillac . . . . .	8-8	Front Doors . . . . .	6-38
Lid Mechanical Pull-Down Unit		Lock Assembly and Vacuum Actuator -	
Adjustment - Rear Compartment -		"B-35-45-69" Styles -	
Cadillac . . . . .	8-10	Rear Doors . . . . .	6-95
Lid Mechanical Pull-Down Unit Cable -		Lock Control Assembly -	
Rear Compartment -		Reclining Front Strato Seat Back . . . . .	15-33
Cadillac . . . . .	8-9	Lock Control Support -	
Lid Mechanical Pull-Down Unit Hydraulic		Reclining Front Strato Seat Back . . . . .	15-33
Cylinder - Rear Compartment - Cadillac	8-9		

Subject	Page No.	Subject	Page No.
Lock Cylinder Assembly - Front Doors . . . . .	6-39	Lock Remote Control Assembly, Vacuum - Front Doors . . . . .	6-81
Lock Cylinder and Lid Emblem Assembly - Rear Compartment - Cadillac . . . . .	8-4	Lock, Seat Back - "A, B & Z" - Standard Front Seat . . . . .	15-19
Lock Cylinder - Front Compartment Lid - Corvair . . . . .	5-9	Lock, Seat Back - "C & E" - Standard Front Seat . . . . .	15-19
Lock Cylinder, Luggage Compartment - 15-16000 Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-45	Lock, Second Seat Back - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52
Lock Cylinder - Rear Compartment Lid - Chevrolet "A & F", Pontiac "A & B" (Except 26657), Oldsmobile "B" . . . . .	8-4	Lock Selector Valve, Vacuum - Front Doors . . . . .	6-79
Lock Cylinder - Rear Compartment Lid - Pontiac 26657 . . . . .	8-5	Lock Storage Tank, Vacuum - Front Doors . . . . .	6-81
Lock Cylinder - Rear Compartment Lid - Oldsmobile "E" . . . . .	8-5	Lock Strikers - Front and Rear Doors . . . . .	6-7
Lock Electric Release Unit - Rear Compartment Lid - Pontiac "A & B" . . . . .	8-11	Lock Strikers - Front Compartment Lid - Corvair . . . . .	5-10
Lock, Folding Second Seat Back - Station Wagon Folding Two Seat Styles - "A, B & X" (Except "55" & "65") . . . . .	15-48	Lock Strikers - Rear Compartment Lid . . . . .	8-6
Lock, Front Back - Standard Bucket . . . . .	15-26	Lock Strikers - Tail Gate . . . . .	9-10
Lock Lubrication - Front Compartment Lid . . . . .	2-2	Lock Striker Adjustments - Tail Gate . . . . .	9-11
Lock Lubrication - Rear Compartment Lid . . . . .	2-5	Lock Striker Engagement - Rear Compartment Lid - All Except Corvair and Cadillac with Mechanical Closing Unit . . . . .	8-6
Lock, Luggage Compartment - 15-16000 Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-45	Lock Striker Lubrication - Door . . . . .	2-1
Lock Mechanism and Lock Parts Lubrication - Door Lock . . . . .	2-2	Lock Striker Lubrication (Station Wagon) - Tail Gate . . . . .	2-5
Lock Parts and Lock Mechanism Lubrication - Door Lock . . . . .	2-2	Lock System, Vacuum - Front Door . . . . .	6-78
Lock Release - Rear Compartment Lid - Electric . . . . .	8-11	Lock Trouble Diagnosis Procedure, Vacuum - Front Doors . . . . .	6-82
Lock Remote Control - All Styles - Rear Doors . . . . .	6-87	Lock Vacuum Actuator - Front Doors . . . . .	6-39
Lock Remote Control - Front Doors . . . . .	6-36	Lock Vacuum Actuator - 68069 and 68169 Styles - Rear Door . . . . .	6-96
Lock Remote Control Assembly - Tail Gate . . . . .	9-9	Lower Channel and Plastic Slides - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-16
		Lower Glass Run Channels - Tail Gate Window . . . . .	9-7

O

Subject	Page No.	Subject	Page No.
Outside Handle - Tail Gate Window Regulator - Manual or Electric . . . . .	9-7	Pull-Down Unit Cable - Rear Compartment Lid Mechanical - Cadillac . . . . .	8-9
Outer and Inner Strip Assemblies - Tail Gate Window . . . . .	9-12	Pull-Down Unit Hydraulic Cylinder - Rear Compartment Lid - Mechanical - Cadillac . . . . .	8-9
Outer Linkage, Second Seat Side - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52	Pull Handles - Door . . . . .	14-1
Outer Strip Assembly - Rear Quarter Window - All Closed Styles . . . . .	7-9	Pump Assembly Operation - Hydro-Lectric System . . . . .	13-28
<b>P</b>		<b>Q</b>	
Panel and Linkage (Full Width of Split Seat), Second Seat Back Trim - Station Wagon Rear Seats - "B" Body . . . . .	15-44	Quarter Anchorage (Convertibles) - Shoulder Straps . . . . .	15-60
Panel and Seat Back - Station Wagon Folding Rear Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47	Quarter Trim - Rear . . . . .	14-9
Panel Hinge, Luggage Compartment Front and Rear - Station Wagon Rear Seat - "B" Body . . . . .	15-41	Quarter Window Regulator Cams and Guides Lubrication - Rear . . . . .	2-4
Passenger Front Bucket Seat Back Stop Cable or Spring . . . . .	15-25	<b>R</b>	
Plastic Slides - Standard Front Seats - "C" Body - Two-Way . . . . .	15-7	Rear and Front Panel Assembly, Luggage Compartment - Two Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-41
Plastic Slides and Lower Channel - Standard Front Seat - "B, C & E" Body - Six-Way . . . . .	15-16	Rear Compartment . . . . .	8-1
Positioning Unit, Seat Back - Reclining Strato Front Seat . . . . .	15-32	Rear Compartment Floor Panel (At Kick-Up) - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47
Power Operated Horizontal Adjuster - Front Strato Seat . . . . .	15-34	Rear Compartment Floor Panel Covering - Station Wagon Styles with Floor Carpet - "A" Body Except "65" Styles . . . . .	15-41
Power Operated Two or Four-Way Bucket Assembly - Front Seat . . . . .	15-24	Rear Compartment Floor Panel Covering - Station Wagon Styles with Rubber Mat - "A" Body Except "65" Styles . . . . .	15-41
Power Operated Four-Way Adjuster - Front Strato Seat . . . . .	15-34	Rear Compartment Floor Panel Covering - Station Wagon Styles with Vinyl Mat - "A" Body Except "65" Styles . . . . .	15-4
Pull-Down Unit - Rear Compartment Lid Mechanical - Cadillac . . . . .	8-8	Rear Compartment Hinge and Torque Rod Lubrication . . . . .	2-5
Pull-Down Unit Adjustment - Rear Compartment Lid - Mechanical - Cadillac . . . . .	8-10	Rear Compartment Lid Lock Lubrication . . . . .	2-5

Subject	Page No.	Subject	Page No.
Rear Compartment Weatherstrips - All Styles . . . . .	8-11	Rear Quarter Trim Assemblies "A-B-C" Body and "69 and 39" Styles . . . . .	14-17
Rear Door Hinge Hold-Open Assembly Lubrication . . . . .	2-1	Rear Quarter Trim Assemblies - "A-B-C" Two-Door Styles (Hang-On Type) . . . . .	14-12
Rear Floor Filler Panel - Station Wagon Folding Rear Two Seat Styles - "A" Except "65" Styles . . . . .	15-47	Rear Quarter Trim Assemblies - "A-X-Z" Two-Door Styles (Insert Type) . . . . .	14-14
Rear Floor Filler Panel - Station Wagon Rear Seats - "B" Body . . . . .	15-43	Rear Quarter Trim Assemblies - "A-80" Styles . . . . .	14-16
Rear Floor Pan Linkage, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51	Rear Quarter Trim Assemblies - "E" Styles . . . . .	14-15
Rear Floor to Tail Gate Filler Panel Assembly - 25-26000 Series - Station Wagon Rear Seats . . . . .	15-39	Rear Quarter Trim Assemblies - "F" Styles . . . . .	14-15
Rear Glass Run Channel - "A-17-39-67" Styles - Front Door Window . . . . .	6-73	Rear Quarter Trim Assemblies - "Z-39" Styles . . . . .	14-17
Rear Glass Run Channel - "Z" Styles - Front Door Window . . . . .	6-75	Rear Quarter Trim Panel (Left Side) - "B" Station Wagon Styles . . . . .	14-18
Rear Guide - 26657 Style - Front Door Window . . . . .	6-77	Rear Quarter Wheelhouse Cover Panel (Right Side) - "B" Body - Station Wagon Styles . . . . .	14-19
Rear Guide Assembly - "F" Styles - Front Door Window . . . . .	6-74	Rear Quarter Wheelhouse Trim Cover - Chevy II Station Wagon Styles . . . . .	14-24
Rear Guide Assembly - Rear Quarter Window - "A-X-Z" Hardtop and Convertible Styles and "E-87" Styles . . . . .	7-26	Rear Quarter Window - Adhesive Caulked Type . . . . .	4-12
Rear Guide Channel - "E" Styles - Front Door Window . . . . .	6-74	Rear Quarter Window - Rubber Channel - Adhesive Caulked Type . . . . .	4-15
Rear Quarter Arm Rest . . . . .	14-10	Rear Quarter Window Regulator Cams and Guides Lubrication . . . . .	2-4
Rear Quarter Front Trim Panel - "A" Styles - Station Wagon . . . . .	14-20	Rear Quarter Window Regulator Handle . . . . .	14-9
Rear Quarter Front Trim Panel - Chevy II Station Wagon Styles . . . . .	14-24	Rear Seat and Station Wagon Full Width Second Seat - Seat Belts . . . . .	15-55
Rear Quarter Rear Trim Panel - All Station Wagon Styles Except 13435 and 23335 . . . . .	14-21	Rear Seat Back (Except "F & Z") . . . . .	15-37
Rear Quarter Rear Trim Panel - Chevy II Station Wagon Styles . . . . .	14-23	Rear Seat Cushion . . . . .	15-37
Rear Quarter Rear Trim Panel (Left Side) - 13435 and 23335 Styles . . . . .	14-22	Rear Seat Back and Panel - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47
Rear Quarter Trim . . . . .	14-9	Rear Seat Back Center Arm Rest and Curtain . . . . .	15-39
		Rear Seat Back Center Arm Rest Hanger Plate and Linkage . . . . .	15-39

Subject	Page No.	Subject	Page No.
Rear Seat Back Trim and Spring - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47	Regulator Cams and Guide Lubrications - Window - Styles with Upper Frames . . . . .	2-2
Rear Seat Cushion - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-46	Regulator Electric Motor Removal - Rear Door Windows . . . . .	6-116
Rear Trim Panel - Rear Quarter - All Station Wagon Styles Except 13435 and 23335 . . . . .	14-21	Regulator Motor Assembly - Tail Gate Electric Window . . . . .	9-5
Rear Trim Panel - Rear Quarter - Chevy II Station Wagon Styles . . . . .	14-23	Regulator Outside Handle - Tail Gate Window - Manual or Electric . . . . .	9-7
Rear Trim Panel (Left Side) - Rear Quarter - 13435 and 23335 Styles . . . . .	14-22	Regulator, Ventilator - Manual and Electric - ("B-C" Styles) - Front Doors . . . . .	6-41
Rear Vertical Gearnut - Standard Front Seats - "B, C & E" Body - Six-Way . . . . .	15-15	Regulator - Manual or Electric - 26657 Style - Front Door Window . . . . .	6-71
Rear Vertical Inner Sealing Strip - Rear Quarter Window - "C-47" Styles . . . . .	7-9	Regulator Electric Motor - Front Door Window . . . . .	6-72
Reclining Front Seat Back . . . . .	15-30	Release Unit - Rear Compartment Lid Lock Electric - Pontiac "A & B" Styles . . . . .	8-11
Regulator - Electric - "B-35-45-69" Styles - Front Door Window . . . . .	6-72	Release Unit - Rear Compartment Lid Vacuum . . . . .	8-7
Regulator - Manual and Electric - All "B-C" Except "B-11-35-45-57-69" Styles - Front Door Window . . . . .	6-71	Remote Control Assembly - Tail Gate Lock . . . . .	9-9
Regulator - Manual and Electric - "A-E-F-X-Z" Styles - Front Door Window . . . . .	6-70	Remote Control Assembly, Vacuum Lock - Front Doors . . . . .	6-81
Regulator - Manual and Electric - All "B & C" Styles - Rear Door Window . . . . .	6-114	Remote Control Inside Handle - "B" Styles - Tail Gate . . . . .	9-9
Regulator - Manual or Electric - Tail Gate Window . . . . .	9-5	Reservoir Tube - Hydro-Lectric System - Folding Top . . . . .	13-28
Regulator and Cam Lubrication - Door Window - Styles with Upper Frames . . . . .	2-2	Retainer, Buckle - Shoulder Straps . . . . .	15-60
Regulator Assembly - "A-Z 39" Styles Rear Door Window . . . . .	6-116	Retractor, Bail Type - Seat Belt . . . . .	15-55
Regulator Assembly - "A-35-55-65 & 69" Styles and "X35 & 69" Styles - Rear Door Window . . . . .	6-114	Retractor Type Floor Mount - Seat Belts . . . . .	15-55
Regulator and Cams Lubrication - Tail Gate Window (Station Wagon) . . . . .	2-5	Roof Anchorage (Closed Styles) - Shoulder Straps . . . . .	15-59
Regulator Cams and Guides Lubrication - Rear Quarter Window . . . . .	2-4	Roof Rail Weatherstrip Adjustment, Side - Front and Rear Doors . . . . .	6-14
		Roof Rail Weatherstrip Retainer, Side - Front and Rear Doors . . . . .	6-10
		Rotary Bolt and Fork Bolt Lubrication - Door Lock . . . . .	2-1
		Run Channel - "A-17-39-67" Styles - Front Door Rear Window Glass . . . . .	6-73

Subject	Page No.	Subject	Page No.
Run Channel - "A-35-55-65 & 69" Styles - Rear Door Window Glass . . . . .	6-110	Seat Assembly - Standard Front Seats . . . . .	15-3
Run Channel - "B-11-35-45-69" Styles - Front Door Window Glass . . . . .	6-76	Seat Assembly - Power Operated Standard Front Seats . . . . .	15-5
Run Channel - "B-35-45 & 69" Styles - Rear Door Window Glass . . . . .	6-111	Seat Back and Panel - Station Wagon Folding Rear Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47
Run Channel - "X-11-35-69" Styles - Front Door Window Glass . . . . .	6-75	Seat Back Assembly - "A-39" Styles with Arm Rest - Standard Front Seat . . . . .	15-18
Run Channel - "X-37" Styles - Front Door Window Glass . . . . .	6-75	Seat Back Assembly - Four Door with Standard Front Seat . . . . .	15-17
Run Channel - "X-35-69" Styles - Rear Door Window Glass . . . . .	6-113	Seat Back Assembly - Reclining Strato Front Seat . . . . .	15-32
Run Channel - "Z" Styles - Front Door Window Rear Glass . . . . .	6-75	Seat Back Assembly (Right or Left) - Two Door with Standard Front Seat . . . . .	15-18
Run Channel, Glass - Inner and Outer Strip Assemblies - Front and Rear Doors . . . . .	6-9	Seat Back, Front Reclining . . . . .	15-30
Run Channel - Tail Gate Upper Glass - "A & B" Body . . . . .	9-13	Seat Back Headrest - Full Width Seat - Standard Front Seat . . . . .	15-21
Run Channel - Tail Gate Upper Glass - "X" Body . . . . .	9-14	Seat Back Linkage, Second (Full Width Both Sides, Split Seat - Outer Only) . . . . .	15-44
<b>S</b>		Seat Back Lock - "A, B & Z" - Standard Front Seat . . . . .	15-19
Sash Channel Cam - "E-F-Z" Styles - Front Door Lower Window . . . . .	6-53	Seat Back Lock - "C & E" - Standard Front Seat . . . . .	15-19
Sash Channel Cam, Lower - All Except "X" Styles - Rear Door Window . . . . .	6-96	Seat Back Lock and Striker - Reclining Front Strato Seat . . . . .	15-32
Sash Channel Guide Plate - "A-17-39-67" Styles - Front Door Window . . . . .	6-54	Seat Back Panel, Folding Third - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42
Sealing - Rear Quarter Inner Panel . . . . .	7-2	Seat Back Positioning Unit - Reclining Strato Front Seat . . . . .	15-32
Sealing Strip - Front and Rear Door Bottom Auxiliary . . . . .	6-3	Seat Back, Rear (Except "F & Z") . . . . .	15-37
Sealing Strip - Front and Rear Door Bottom Drain Hole . . . . .	6-3	Seat Back Stop Cable or Spring, Passenger Front Bucket . . . . .	15-25
Sealing Strip - Tail Gate Bottom Drain Hole . . . . .	9-12	Seat Back Trim, Folding Third - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42
Seat Adjuster Mechanism Lubrication - Front . . . . .	2-6	Seat Back Trim, Panel and Linkage - (Full Width or Split Seat), Second - Station Wagon Rear Seats - "B" Body . . . . .	15-44

Subject	Page No.	Subject	Page No.
Seat Back Trim (Full Width or Split Seat), Second - Station Wagon Rear Seat - "B" Body . . . . .	15-43	Second Seat Rear Floor Pan Linkage - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
Seat Belt Bail Type Retractor . . . . .	15-55	Second Seat Side Inner Linkage - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
Seat Belts, Front and Rear . . . . .	15-54	Second Seat Side Outer Linkage - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52
Seat Center Arm Rest, Front - Standard Front Seat . . . . .	15-21	Second Seat Split Back Inner Linkage - Station Wagon Rear Seats - "B" Body . . . . .	15-45
Seat Cushion, Folding Third - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42	Selector Valve, Vacuum Lock - Front Door . . . . .	6-79
Seat Linkage Lubrication - Folding . . . . .	2-5	Shoulder Strap - Front Seat . . . . .	15-55
Second Seat Assembly - Right or Left - Station Wagon Folding Rear Seats - "A-65" . . . . .	15-49	Shroud Side Air Outlet Duct Door Body Ventilation - "A, B, C, D & E" . . . . .	5-2
Second Seat Back Linkage (Full Width Both Sides, Split Seat - Outer Only) . . . . .	15-44	Shroud Side Air Outlet Duct Door Body Ventilation - "F, X & Z" . . . . .	5-3
Second Seat Back Lock - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52	Shroud Side Air Outlet Duct Door Control Cable Body Ventilation - "F, X & Z" . . . . .	5-5
Second Seat Back Lock - Station Wagon Folding Two Seat Styles - "A, B & X" Except "55 & 65" . . . . .	15-48	Shroud Side Air Outlet Duct Door Control Cable Body Ventilation - "A, B, C, D & E" . . . . .	5-3
Second Seat Back Panel and Filler - Right or Left - Station Wagon Folding Rear Seat - "A-65" Style . . . . .	15-52	Shroud Side Finishing Panel and Air Outlet Duct Body Ventilation - "F, X & Z" . . . . .	5-2
Second Seat Back Trim (Full Width or Split Seat) - Station Wagon Rear Seats - "B" Body . . . . .	15-43	Shroud Side Finishing Panel Body Ventilation - "A, B, C, D & E" . . . . .	5-1
Second Seat Back Trim and Spring - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-50	Side and Center Trim Panels - Compartment Shelf - Cadillac "E" Styles . . . . .	14-27
Second Seat Back Trim, Panel and Linkage (Full Width or Split Seat) - Station Wagon Rear Seats - "B" Body . . . . .	15-44	Side Filler Panel, Compartment Pan - Station Wagon Rear Seat - "B" Body . . . . .	15-40
Second Seat Cushion (Full Width or Split Seat) - Station Wagon Rear Seats - "B" Body . . . . .	15-43	Side Finishing Panels - Compartment Shelf - Oldsmobile and Buick "E" Styles . . . . .	14-26
Second Seat Cushion - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-50	Side Inner Linkage, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51
Second Seat Front Floor Pan Linkage - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-51		

Subject	Page No.	Subject	Page No.
Side Outer Linkage, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-52	Station Wagon Third Seat (Facing Forward) - Seat Belts . . . . .	15-55
Side Roof Rail Weatherstrip Adjustment - Front and Rear Doors . . . . .	6-14	Station Wagon Third Seat (Facing Rearward) - Seat Belts . . . . .	15-55
Side Roof Rail Weatherstrip and Retainer - Front and Rear Doors . . . . .	6-10	Stationary Ventilator Assembly - "X-35 & 69" Styles - Rear Door Window . . . . .	6-98
Silencer - Folding Top . . . . .	13-24	Stationary Ventilator Division Channel - "X-35 & 69" Styles - Rear Door Window . . . . .	6-97
Skylight - Windows - Adhesive Caulking . . . . .	4-9	Stop Cable or Spring, Passenger Front Bucket Seat Back . . . . .	15-25
Slides, Plastic - Standard Front Seats - "C" Body - Two-Way . . . . .	15-7	Storage Tank, Vacuum Lock - Front Doors . . . . .	6-81
Spare Tire Cover Panel - "A" Station Wagon Styles . . . . .	14-20	Strato Back Assembly - Full Width (16639 Styles) - Front Seat . . . . .	15-27
Spare Tire Cover Panel - "B" Station Wagon Styles . . . . .	14-18	Strato Back Assembly - Full Width (Except 16639) - Front Seat . . . . .	15-26
Specified Body Opening Clearance Tolerances - Front and Rear Doors . . . . .	6-15	Strato Back Assembly (Except "F & Z" and Reclining Back) - Front Seats . . . . .	15-29
Split Back Inner Linkage, Second Seat - Station Wagon Rear Seats - "B" Body . . . . .	15-45	Strato Back Lock - Two Door Styles - Front Seat . . . . .	15-29
Split Second Seat, Station Wagon - Seat Belts . . . . .	15-55	Strato Back Headrest - Front Seat . . . . .	15-28
Spring and Back Trim, Rear Seat - Station Wagon Folding Two Seat Styles - "A" Body Except "65" Styles . . . . .	15-47	Strato Back Headrest Supports - Front Seat . . . . .	15-29
Spring and Back Trim, Second Seat - Right or Left - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-50	Strato Back Headrest Support Guide Tube - Front Seat . . . . .	15-28
Spring Clips - Front and Rear Doors . . . . .	6-6	Strato Back Panel - Two Door Styles - Front Seat . . . . .	15-28
Spring or Stop Cable, Passenger Front Bucket Seat Back . . . . .	15-25	Strato Back Panel - Four Door Styles - Front Seat . . . . .	15-27
Standard Floor Mounts with Plastic Cover - Seat Belts . . . . .	15-52	Strato Full Width Seat Assembly - Front / . . . . .	15-23
Station Wagon Folding Rear Seats and Floor Panels - "B" Body . . . . .	15-39	Strato Full Width, Strato Bucket and Standard Bucket Seats . . . . .	15-23
Station Wagon Full Width and Rear Seat Second Seat - Seat Belts . . . . .	15-55	Striker - Front Compartment Lid Lock - Corvair . . . . .	5-10
Station Wagon Split Second Seat - Seat Belts . . . . .	15-55	Striker - Rear Compartment Lid Lock . . . . .	8-6

Subject	Page No.	Subject	Page No.
Striker and Back Lock - Reclining Front Strato Seat . . . . .	15-32	Third Seat Back Panel, Folding - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42
Striker Engagement - Rear Compartment Lid Lock - All Except Corvair and Cadillac with Mechanical Closing Unit . . . . .	8-6	Third Seat Back Trim, Folding - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42
Strikers, Lock - Front and Rear Doors . . . . .	6-7	Third Seat Back Trim or Seat Back Panel - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-54
Striker Lubrication - Door Lock . . . . .	2-1	Third Seat Cushion Trim - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-53
Striker Lubrication - Tail Gate Lock (Station Wagon) . . . . .	2-5	Third Seat Cushion, Folding - Three Seat Styles - Station Wagon Rear Seat - "B" Body . . . . .	15-42
Support and Arm Rest - Standard Full Width Seat Back - Standard Front Seat . . . . .	15-21	Third Seat Cushion, Folding, Panel and Support - Three Seat Styles - Station Wagon Rear Seats - "B" Body . . . . .	15-42
Support, Arm Rest - Notch Down and Strato Seat Back - Standard Front Seat . . . . .	15-22	Torque Rods - Front Compartment Lid - Corvair . . . . .	5-8
Support Assemblies - Tail Gate . . . . .	9-2	Torque Rod - Tail Gate . . . . .	9-11
Support Guide Tube, Strato Back Headrest - Front Seat . . . . .	15-28	Torque Rod Adjustment - Rear Compartment Lid . . . . .	8-3
Supports, Strato Back Headrest - Front Seat . . . . .	15-29	Torque Rod and Hinge Lubrication - Rear Compartment . . . . .	2-5
<b>T</b>		Torque Tube Assembly - Power Operated Four-Way Adjuster - Strato Front Seat . . . . .	15-37
Tail Gate Assembly . . . . .	9-3	Transmission Assembly and Drive Cables - Power Operated Four-Way Adjuster - Front Strato Seat . . . . .	15-36
Tail Gate Bottom Drain Hole Sealing Strips . . . . .	9-12	Transmission Drive Belt and Pulleys and Motor - Power Operated Four-Way Adjuster - Front Strato Seat . . . . .	15-35
Tail Gate Fabric Cover . . . . .	12-10	Transmission - Standard Front Seats - "A" Body - Four-Way . . . . .	15-11
Tail Gate Hinge Lubrication (Station Wagon) . . . . .	2-5	Transmission - Standard Front Seats - "B, C & E" Body - Four-Way . . . . .	15-13
Tail Gate Lock Striker Lubrication (Station Wagon) . . . . .	2-5		
Tail Gate Window Regulator and Cam Lubrication (Station Wagon). . . . .	2-5		
Third Seat (Facing Forward), Station Wagon - Seat Belts . . . . .	15-55		
Third Seat (Facing Rearward), Station Wagon - Seat Belts . . . . .	15-55		
Third Seat and Floor Panel - Station Wagon Folding Rear Seat - "A-65" Styles . . . . .	15-53		

**V**

**W**

Subject	Page No.	Subject	Page No.
Weatherstrip - Center Pillar - "C-69" Styles - Front and Rear Doors . . . . .	6-14	Window Assembly - "A and X" Closed Styles - Front Doors . . . . .	6-51
Weatherstrip Retainer, Side Roof Rail - Front and Rear Doors . . . . .	6-10	Window Assembly - "A-17-67" Styles - Front Doors . . . . .	6-56
Weatherstrip, Ventilator - "A & F" Styles - Front Doors . . . . .	6-47	Window Assembly - "A-39" Styles - Front Door . . . . .	6-55
Wedge Plates - "67" Styles - Front Door . . . . .	6-78	Window Assembly - All "B-C" Except B-11-35-45-57-69" Styles - Front Door . . . . .	6-65
Wheelhouse Cover Panel (Right Side) - Rear Quarter - "B" Station Wagon Styles . . . . .	14-19	Window Assembly - "B-11-35-45-69" Styles - Front Doors . . . . .	6-64
Wheelhouse Trim Cover - Rear Quarter - Chevy II Station Wagon Styles . . . . .	14-24	Window Assembly - "E" Styles - Front Doors . . . . .	6-58
Wheelhouse Trim Cover Assembly (left side) - All "A" Station Wagon Styles Except 23335 . . . . .	14-21	Window Assembly - "F" Styles - Front Doors . . . . .	6-60
Wheelhouse Trim Cover Panel (Right Side) - "A" Station Wagon Styles . . . . .	14-20	Window Assembly - "X-37" Styles - Front Doors . . . . .	6-62
Window Adjustments - Rear Quarter - "A & B" Closed Styles . . . . .	7-3	Window Assembly - "Z" Styles - Front Doors . . . . .	6-63
Window Adjustments - Rear Quarter - "X" Closed Styles . . . . .	7-4	Window Assembly - 26657 Style - Front Doors . . . . .	6-67
Window and Ventilator Adjustments - 68069 & 68169 Styles - Rear Doors . . . . .	6-107	Window Assembly - Manual or Electric - Tail Gate . . . . .	9-4
Window Assembly - "A-39" Styles - Rear Doors . . . . .	6-99	Window Assembly - Rear Quarter - All Hardtop and Convertible Styles Except "B-C" . . . . .	7-10
Window Assembly - All "B-C 39" Styles and All "C-49 & 69" Styles Except 68069 and 68169 Styles - Rear Doors . . . . .	6-103	Window Assembly - Rear Quarter - "A & B-11" and "A-07" Styles . . . . .	7-2
Window Assembly - All Closed Styles - Rear Doors . . . . .	6-99	Window Assembly - Rear Quarter - "B-C 47-57-67-87" Styles . . . . .	7-20
Window Assembly - 68069 and 68169 Styles - Rear Doors . . . . .	6-104	Window Assembly - Rear Quarter - "X-11" Style . . . . .	7-4
Window Assembly - "Z-39" Styles - Rear Door . . . . .	6-108	Window Electric Regulator Motor Assembly - Tail Gate . . . . .	9-5
		Window Front Glass Run Channel - Rear Quarter - All Closed Styles . . . . .	7-8
		Window Front Guide Channel - "E" Styles - Front Doors . . . . .	6-74

Subject	Page No.	Subject	Page No.
Window Front Guide - Rear Quarter - "B-C 47-57-67-87" Styles . . . . .	7-25	Window Lower Glass Run Channels - Tail Gate . . . . .	9-7
Window Front Guide - 26657 Style - Front Doors . . . . .	6-76	Window Lower Sash Channel Cam - "E-F-Z" Styles - Front Doors . . . . .	6-53
Window Front Guide Assembly - Rear Quarter - "A-X-Z" Hardtop and Convertible Styles and "E-87" Styles . . . . .	7-25	Window Lower Sash Channel Cam - All Except "X" Styles - Rear Doors . . . . .	6-96
Window Front or Rear Guide - "Z-39" Styles - Rear Doors . . . . .	6-114	Window Outer Strip Assembly - Rear Quarter - All Closed Styles . . . . .	7-9
Window Glass Run Channel - "A-35-55-65 & 69" Styles - Rear Doors . . . . .	6-110	Window Rear Glass Run Channel - "A-17-39-67" Styles - Front Doors . . . . .	6-73
Window Glass Run Channel - "B-11-35-45-69" Styles - Front Doors . . . . .	6-76	Window Rear Glass Run Channel - "Z" Styles - Front Doors . . . . .	6-75
Window Glass Run Channel - "B-35-45 & 69" Styles - Rear Door . . . . .	6-111	Window Rear Glass Run Channel - Rear Quarter - All Closed Styles . . . . .	7-7
Window Glass Run Channel - Rear Quarter - "E-47" Styles . . . . .	7-26	Window Rear Guide - 26657 Styles - Front Doors . . . . .	6-77
Window Glass Run Channel - "X-37" Styles - Front Doors . . . . .	6-75	Window Rear Guide Assembly - Rear Quarter - "A-X-Z" Hardtop and Convertible Styles and "E-87" Styles . . . . .	7-26
Window Glass Run Channel - "X-11-35-69" Styles - Front Doors . . . . .	6-75	Window Rear Guide Channel - "E" Styles - Front Door . . . . .	6-74
Window Glass Run Channel - "X-35 & 69" Styles - Rear Doors . . . . .	6-113	Window Rear Guide Assembly - "F" Styles - Front Door . . . . .	6-74
Window Guide (Front or Rear) - All "B-C 39" & "C-49-69" Styles Except 68069 - 68169 Styles - Rear Doors . . .	6-112	Window Rear Vertical Inner Sealing Strip - Rear Quarter - "C-47" Styles . . . . .	7-9
Window Guide and Guide Plate Assembly - All "B-C" Except "B-11-35-45-57-69" Styles - Front Doors . . . . .	6-76	Window Regulator - Electric - "B-35-45-69" Styles - Front Doors . . . . .	6-72
Window Guide Assembly - Rear Quarter - All "F" Styles . . . . .	7-26	Window Regulator - Manual - "B-11-35-45-69" Styles - Front Doors . . . . .	6-72
Window Guide Assembly - Rear Quarter - "X-11" Styles . . . . .	7-8	Window Regulator (Manual or Electric) - Rear Quarter - "A, B & X" Closed Styles . . . . .	7-5
Window Guide Channels - "A-39" Styles - Rear Doors . . . . .	6-111	Window Regulator (Manual or Electric) - Front Doors - "A-E-F-X-Z" Styles . . . . .	6-70
Window Inner and Outer Strip Assemblies - Tail Gate . . . . .	9-12		

<b>Subject</b>	<b>Page No.</b>	<b>Subject</b>	<b>Page No.</b>
Window Regulator (Manual or Electric) - Front Doors - All "B-C" Except "B-11-35-45-57-69" Styles . . . . .	6-71	Window Regulator Cams and Guides Lubrication - Rear Quarter . . . . .	2-4
Window Regulator (Manual or Electric) - Rear Doors - All "B & C" Styles . . . . .	6-114	Window Regulator Cams and Guides Lubrication - Styles with Upper Frames . . . . .	2-2
Window Regulator (Manual or Electric) - Rear Quarter - "B-C 47-57-67- 87" Styles . . . . .	7-22	Window Regulator Electric Motor - Front Doors . . . . .	6-72
Window Regulator (Manual or Electric) - 26657 Styles - Front Doors . . . . .	6-71	Window Regulator Electric Motor Removal - Rear Door . . . . .	6-116
Window Regulator (Manual or Electric) - Tail Gate . . . . .	9-5	Window Regulator Handle - Rear Quarter . . . . .	14-9
Window Regulator and Cam Lubrication, Door - Styles with Upper Frames . . . . .	2-2	Window Regulator Outside Handle - Tail Gate - Manual or Electric . . . . .	9-7
Window Regulator and Cam Lubrication, Tail Gate - Station Wagon . . . . .	2-5	Window Sash Channel Guide Plate - "A-17-39-67" Styles - Front Doors . . . . .	6-54
Window Regulator Assembly (Manual or Electric) - Rear Quarter - "A, E, F, X & Z" Hardtop and Convertible Styles . . . . .	7-24	Window Stationary Ventilator Assembly - "X-35 & 69" Styles - Rear Doors . . . . .	6-98
Window Regulator Assembly - "A-Z 39" Styles - Rear Doors . . . . .	6-116	Window Stationary Ventilator Division Channel - "X-35 & 69" Styles - Rear Doors . . . . .	6-97
Window Regulator Assembly - "A-35-55-65 & 69" Styles and "X-35 & 69" Styles - Rear Doors . . . . .	6-114	Window Up-Travel Stops - All Except "B-C" Styles - Front Doors . . . . .	6-55
		Windshield Glass - Rubber Channel - Adhesive Caulking . . . . .	4-7
		Windshield Glass - Adhesive Caulked Type . . . . .	4-4